

## *RIBP D/Plot from AutoCAD 2000/'02/'04*

### **STEP ONE: AutoCAD Configuration**

- Launch AutoCAD
- Under the File Menu, select PLOTTER MANAGER
- Use the Add a Plotter Wizard to assist in creating the New Plotter for Plot To File
- The Add Plotter Intro Page comes up, Click on NEXT
- Choose MY COMPUTER and click on NEXT
- Under MANUFACTURERS, choose Hewlett-Packard
- Under Models choose DesignJet 750C Plus C4709B. Click on Next
- Disregard the warning and click Continue
- You now have the option to import your PCP or Pc2 File at this time. If you choose to, click on import file, do so, and then click on Next. Otherwise, just click Next.
- Choose Plot To File and then click on Next.
- Enter a name for your new plotter - RIBP D/Plot - and click on Next.
- Click on Finish.
- Plot To File potter is now available.

### **STEP TWO: Writing a .PLT File**

- To begin, open up your first drawing
- Select PLOT from the File Menu
- In the upper left corner of the window, make sure Save Changes To Layout is checked
- Under Plot Device, Plotter Configuration, choose RIBP D/Plot
- Under Plot to File, make sure Plot To File is checked
- Check the File Name and Save Location in the bottom right corner
- Assign a Plot Style Table (Pen Assignments) or Choose to Edit or Create a New Table (ctb)
- In the Plot Style Table Editor, assign all colors to Black and set Line Weights
- After selecting the Pen Assignments, Save and Close the dialogue box (be sure to check whether your line weights are millimeters or inches).
- Click on the Plot Settings tab and set your Paper Size, Orientation, Plot Area & Scale
- Choose Full Preview to verify that the plot is correct
- Finish the plot by clicking on OK
- You now have successfully created a plot file to send to RIBP !

Questions?

Call 401.942.3225  
or 800.734.3225

or Email:  
Digital@RIBP.com